Addonics
TECHNOLOGIES

User Guide

Z Family DVD+/-R/RW Burner with eSATA/USB 3.0

(ZDRWESU3)

www.addonics.com

Technical Support

If you need any assistance to get your unit functioning properly, please have your product information ready and contact Addonics Technical Support at:

Hours: 8:30 am - 6:00 pm PST
Phone: 408-453-6212
Email: http://www.addonics.com/support/query/

Unpacking and Overview

ZDRWESU3 unit



Rear view

ADU3ESA Adapter

12V Power Supply
(US Version Shown)

100 cm eSATA cable

Connecting to a Host

eSATA

Before connecting the Z DVD Writer to a computer using eSATA, be sure the computer's eSATA controller supports hot swapping. If the computer's eSATA controller does not support hot swapping, turning the unit on or off, connecting or disconnecting the eSATA cable while the computer is running may cause the computer to crash.
The Z DVD Writer will appear to the operating system normally as an internal optical drive would when connected using eSATA. No drivers are required.

USB

When connecting the Z DVD Writer to a computer using USB, first connect the eSATA cable from the Z DVD Writer unit to the eSATAp side of the ADU3ESA adapter, then conenct the USB side of the ADU3ESA adapter to a USB 2.0 or 3.0 port on the computer. The eSATAp side of the ADU3ESA adapter supports hot swapping, as does the USB connection itself. No special features are required before turning the unit on or off, connecting or disconnecting either the eSATA cable or the ADU3ESA adapter while the computer is running.
The Z DVD Writer will first appear as a standard USB Plug and Play Mass Storage device to the operating system when connected using the ADU3ESA adapter, and otherwise will appear as an internal optical drive would. No drivers are required.

CONTACT US

www.addonics.com
Phone: 408-573-8580
Fax: 408-573-8588
Email: http://www.addonics.com/sales/query/